

HI-LIFT QUICK REFERENCE

CHRYSLER		DRIVER	FRONT PASSENGER
Caravan / Grand Caravan / Town & Country	★ 1991 - 2007 ⚠	✓	✓
Caravan / Grand Caravan / Town & Country	★ 2005 - 2007 ⚠	✓	
Caravan / Grand Caravan / Town & Country	★ 2008 - 2020 ⚠	✓	✓
Voyager - Short & Long wheelbase	★ 1991 - 2003	✓	✓
FORD		DRIVER	FRONT PASSENGER
Freestar / Monterey	★ 2004 - 2007 ⚠	✓	✓
Windstar	★ 1999 - 2003 ⚠	✓	✓
GENERAL MOTORS		DRIVER	FRONT PASSENGER
Montana/Silhouette/Transport	★ 1997 - 2004 ⚠	✓	✓
Terreza/Uplander/Relay/Venture	★ 1997 - 2004 ⚠	✓	✓
Montana/Silhouette/Transport	★ 2005 - 2009 ⚠	✓	✓
Terreza/Uplander/Relay/Venture	★ 2005 - 2009 ⚠	✓	✓
HONDA		DRIVER	FRONT PASSENGER
Odyssey	★ 1999 - 2004 ⚠	✓	✓
Odyssey	★ 2005 - 2010 ⚠	✓	✓
KIA		DRIVER	FRONT PASSENGER
Sedona	★ 2006 - 2012 ⚠	✓	✓
NISSAN		DRIVER	FRONT PASSENGER
Quest	★ 2011 - 2016 ⚠	✓	✓
TOYOTA		DRIVER	FRONT PASSENGER
Sienna	★ 2004 - 2010 ⚠	✓	✓
Sienna	★ 2011 - 2020 ⚠	✓	✓
VOLKSWAGEN		DRIVER	FRONT PASSENGER
Routan	★ 2009 - 2012	✓	✓
⚠ Due to the age of the application, shipping LEAD TIME of installation kit may vary. Contact us directly for an estimated price and lead time.			